



Shopping List

Sand
Compost or sieved top
soil
Blood meal
Grass seed
Rake
A pot for measuring

A good mix for reseeding bare spots on lawns is:

5 parts sand
2 parts sterilized compost
1 part blood meal
1 part grass seed.

Use a clean pot to measure out the right quantities of each ingredient. Layer the different components into a suitable mixing container.

Thoroughly combine all of the ingredients.

Rake the area you will be reseeding with a metal rake. This will break up the surface of the soil and make it easier for the grass to establish itself.

Spread the mixture evenly over the entire bare spot. Try to cover the whole area with about a ¼" of the reseeding mix. It's a good idea to tamp down the seed by either walking over it or using the back of a rake. Water the seeded area and within a couple of weeks, grass should be sprouting. It's important to keep the area moist until the grass is established.